xR6000 with Embedded Touch Screen Console

Assembly Instructions

Octane FITNESS

Base Box



Console Box

Hardware



A — Embedded Touch Screen & Mast



❶ Slide mast over screws on base; insert B-3 (Qty 4 black zinc; tighten all 6 screws (30 ft-lb).

❷ Attach Embedded Touch Screen to mast with B-14 (Qty 4); connect cables to console side panel (Qty 5) and bottom panel (Qty 2) according to diagrams below.



❸ Align console back and attach with B-14 (Qty 6).

B — Seat & Heart Rate Module



❶ Remove seat axle from carriage (slides out left side of unit).

❷ Lift tilt handle; slide seat assembly onto carriage; re-insert axle and tighten (17 ft-lb).

❸ Lay handlebar across seat assembly; connect 2 heart rate cables(seat tube to base & seat tube to handlebar).

❹ Connect control button cables (seat handles to base).

❺ Attach lower end of damper to base.

❻ Attach handlebar & seat pad with B-4 & B-8 (Qty 4).

❼ Attach accessory holders with B-5 (Qty 6).

❽ Tilt seat forward; insert tilt cable in hole and slide up.

C — Moving Handlebars



❶ Attach moving handlebar at hub with B-2 (Qty 4); tighten to 30 ft-lb.

❷ Slide cover over handlebar base.

OPTIONAL—Adjust moving handlebar for 1" longer or shorter reach:

❸ Remove lower panel.

❹ ***Hold handlebar,*** remove and reposition bolt.

❺ Replace lower panel.
Settings on both handlebars must match.

D — Top Cover & Mast Boot



❶ Connect power, coax, main control, and Ethernet cables from base to matching connections from mast.

❷ Attach top cover with B-1 (Qty 2).

❸ Wrap mast boot around mast.

E — Footrest & Pedals



❶ Slide B-12 (Qty 1) and lower end of pedal onto crank axle.

❷ Attach upper pedal hub with B-13 and B11 (Qty 1).

❸ Attach lower hub with B-6 and B-9 (Qty 1). Press B-10 in hub.

❹ Attach foot rest bracket to mast with B-7 (Qty 4).

F — Level Unit & Set-up



❶ Adjust and lock levelers; ***make sure nut is tight.***

❷ Press leveler caps over stabilizer bar.

❸ Connect Ethernet, Power, and COAX as shown.

❹ Complete First-Time Set-up Procedures (on back of page) and Club Settings (below).

Club Settings

Set Club Settings:

- Tap the Octane logo on the main screen in this pattern:
  Tap "O", tap "E", tap "E", tap "O"
- Enter the passcode "SETT" (7388)
- Club Settings screen will appear.
  Change settings or accept defaults.
- Press "SAVE" to save new settings



Customize These Club Settings:

Max Workout Time (up to 99:00)
Clock Direction (Count Up or Count Down)
Warm-Up (On or Off)
Units (English or Metric)
Languages (Single or Multi)
Menu Language (select from drop-down menu)